

Edwardian Potting house - medium

ASSEMBLY MANUAL

Thank You for purchasing our product

Safety Points and Other Considerations

Our products are built for use based on proper installation and normal residential use, on level ground. Please follow the instruction manual when building your Gazebo/Lindric/Pergola Circle and retain the manual for future maintenance purposes.

Some of the safety and usage measures you may wish to consider include:

- Snow load ratings vary by geographical location. If heavy or wet snowfall occurs, it is advisable to sweep the snow off the roof(s).
- If the product is elevated, any structural and building code requirements are solely the customer's responsibility, and should be abided by.
- In high or gusty wind conditions it is advisable to keep the structure securely grounded.
- Have a regular maintenance plan to ensure screws, doors, windows and parts are tight.

Customer agrees to hold JClass and any Authorized Dealers free of any liability for improper installation, maintenance and repair.

Important - If you receive a broken or missing part. Please contact our Customer Service Center immediately at 01302 366399



Base Preparation

The life of a building depends upon its foundation. It is vitally important that your base is firm, level, square and large enough to accommodate the building you have ordered. Ideally, your garden building should be installed on a flat concrete slab which is unlikely to sink or break up. A thickness of 50 to 100mm is required, depending upon the size and type of building that you have ordered. As an alternative, concrete paving slabs or decking bases may be laid but they should still be level, unlikely to sink at any point and completely cover the area of base required. If you have any doubts concerning the base seek advice from a local builder.

HARDWARE


SIGN: 1 | 4 PCS

standard post




SIGN: 2 | 2 PCS

central post (left)



SIGN: 3 | 2 PCS

central post (right)




SIGN: 4 | 6 PCS

standard bottom ring beam



SIGN: 5 | 6 PCS

standard top ring beam




SIGN: 6 | 2 PCS

central bottom ring beam




SIGN: 7 | 2 PCS

central top ring beam




SIGN: 8 | 4 PCS

standard roof rafter




SIGN: 8a | 2 PCS

left hand side roof rafter




SIGN: 8b | 2 PCS

right hand side roof rafter




SIGN: 9 | 1 PCS

central roof rafter




SIGN:10 | 2 PCS

mid section's support




SIGN:11 | 6 PCS

standard cill




SIGN:12 | 2 PCS

central cill




SIGN:13 | 1 PCS

bottom door stop




SIGN:14 | 1 PCS

top door stop




SIGN:16 7 PCS open sash frame




SIGN:17 7 PCS sash panel



SIGN:18 1 PCS doors



SIGN:19 1 PCS doors



SIGN:20 12 PCS standard beading




SIGN:21 4 PCS mid section side beads



SIGN:22 2 PCS mid section top beads




SIGN:23 24 PCS glazing clip




SIGN:247 PCS

sash panel glass



SIGN:2514 PCS

open sash panel glass




SIGN:262 PCS

top door glass




SIGN:272 PCS

bottom door glass




SIGN:282 PCS

mid section roof glass




SIGN:296 PCS

roof glass




SIGN:305 PCS

staging top




SIGN:315 PCS

stagings legs (right)




SIGN:325 PCS

staging legs (left)




SIGN:335 PCS

legs stretcher




SIGN:345 PCS

legs stretcher




SIGN:352 PCS

mid section staging top




SIGN:364 PCS

mid section staging legs




SIGN:376 PCS

mid section legs stretcher



SIGN:3814 PCS

window stay




SIGN:3928 PCS

window peg



SIGN:401 PCS

door knob



SIGN:411 PCS

estruccion



SIGN:422 PCS

sash bolt




SIGN:432 PCS

bolt keep



SIGN:442 PCS



hook



SIGN:452 PCS

eye






JOIN COMPONENTS

SIGN			PCS
A	4,5 x 80	SCREW	28
B	4 x 50	SCREW	124
C	4,5 x 60	SCREW	78
D	4 x 25	SCREW	60
E	5 x 60	SCREW	64
F	1,2 x 25	NAIL	458
G	2,5 x 35	NAIL	128
H	3 x 25	SCREW	24
		SILICONE	7


STEP 1



STEP 2

REPEATSTEP 1 - 2 TIMES

STEP 3





STEP 4

REPEAT STEP 3 - 2 TIMES


STEP 5

PLACE CREATE SEMENTS IN STEP 2 AND 4 ON THE GROUND

GROUND MUST BE FLAT




STEP 6




STEP 7

LIKE IN STEP 6



STEP 8



SIGN: 5

SIGN: 1

SIGN: 16


SIGN: C

SIGN: 4




STEP 9


LIKE IN STEP 8



STEP 10





STEP 11




STEP 12

REPEAT STEP 11 - 2 TIMES


STEP 13




STEP 14




STEP 15





STEP 16



STEP 17



STEP 18




SIGN: A

SIGN: 5

SIGN: B

SIGN: 4




SIGN: 13

SIGN: 4


SIGN: 14

SIGN: 13

SIGN: 5




SIGN: B




SIGN: A

STEP 19




STEP 20




STEP 21

INSTALL WINDOWS LIKE AS DOOR, HINGES IN WINDOWS HAVE TO BE AT THE TOP.




STEP 22



SIGN: 11

SIGN: 7




SIGN: A

SIGN: 11


SIGN: A

SIGN: 11

SIGN: 7




STEP 23




STEP 24

**TO ASSEMBLE SIGN: 46 IN THE CORNER FROM TWO SIDES OF
THE COLUMN SIGN: 1,2,3 USE NAILS SIGN: F**




STEP 25

TO PUT THE SILICONE ON EDGES WHERE WILL BE ASSEMBLED THE GLASS, THEN TO ASSEMBLE THE GLASS, THEN ON THE GLASS TO ASSEMBLE THE QUARTER THE ROLL AS IN THE STEP 24, TO USE NAILS SIGN: F




STEP 26


TO PUT THE SILICONE ON EDGES WHERE WILL BE ASSEMBLED THE GLASS, THEN TO ASSEMBLE THE GLASS, THEN ON THE GLASS TO ASSEMBLE SIGN: 20, 21, 22 AS IN THE STEP 24, TO USE NAILS SIGN: G




STEP 27




STEP 28



STEP 29



STEP 30



STEP 31


REPEAT STEP 27,28 - 5 TIMES

STEP 32

REPEAT STEP 29,30 - 2 TIMES


STEP 33

PUT IN TABLES INWARDS AS BELOW




STEP 34

**PUT SGN: 38, 39 ON SGN: 16.
TO FIT AND TO MARK THE POSITION SGN: 38, 39.
THEN SCREW IN SCREWS FROM PACKAGE SGN: 38, 39.**



STEP 35

REPEAT STEP 34 ON 2-TH SIDE OF THE WINDOW



STEP 36


REPEAT STEP 34,35 ON OTHER WINDOWS

STEP 37


THE ASSEMBLY SGN: 40




PUT SGN: I FROM THE INTERNAL SIDE DOOR INTO THE HOLE IN THE LOCK.



SCREW ON SGN: II ON THE SGN: I AND SCREW IN SCREWS FROM PACKAGE SGN: 40




PUT SGN: III ON THE SGN: I AND SCREW IN SCREWS FROM PACKAGE SGN: 40. THEN SCREW ON THE SCREW WITH THE KEY FROM PACKAGE SGN: 40




STEP 38

APPLY SGN: 41 TO THE HOLE BELOW SGN: 40, PUT THE KEY TO LOCK, PLACE SGN: 41 SO SO THAT THE KEY BE IN THE MIDDLE. THEN SCREW IN SCREWS FROM PACKAGE SGN: 41





STEP 39

SCREW IN SGN: 42 TO DOOR SCREWS FROM PACKAGE SGN: 42.




PUT SGN: 43 ON SGN: 13 SO SO THAT THE HOLE FIT ON THE PIN FOR SGN: 42, MARK, THEN OPEN DOOR, REMOVE SGN: 43, LOCAL THE GREATER HOLE BORE HOLE WITH THE DRILL DIAMETER 8 ON THE DEPTH 2 CM. THEN SCREW IN SCREWS FROM PACKAGE SGN: 43.




STEP 40

REPEAT STEP 39 AT THE TOP OF DOOR





STEP 41

SCREW ON SGN: 44 SCREWS FROM PACKAGE SGN: 44.



**OPEN DOOR TO THE MOMENT WHERE YOU WANT IT TO BLOCK
SGN: 44, THEN APPLY SGN: 45 AND MARK.
THEN SCREW IN SCREWS FROM PACKAGE SGN: 45.**



STEP 42

REPEAT STEP 41 AT THE 2TH DOOR

